



# QUICKFLEX

OEKO-TEX®  
CONFIDENCE IN TEXTILES  
STANDARD 100 

Class 1  
\*Class 2

 PU	 3 mil	 45° Blade	 MEDIUM pressure	 330°F	 5s	 PEEL: HOT
---	--	---	---	---	---	--

**CARRIER: Adhesive & Transparent Polyester**

**APPLIES ON**

-  Cotton
-  Polyester
-  Acrylic & Similar Fabrics

**CARE**

- Always respect the garment's instructions
- Allow 24 hours after application before washing
- Iron the backside only

**WASH**

- Max 140°F
- Preferably inside out
- Do NOT bleach
- Tumble-dry
- Do NOT Dry-clean

**STORE**

- Up to 1 year
- In a dry room (60-85°F)
- Away from sunlight
- In vertical position

## APPLICATION

1. Cut the material in reverse with the recommended blade
2. Weed the excess material
3. Heat press on the garment at 330°F & Protect the polyester carrier with silicone paper 5 sec - medium pressure
4. Peel the carrier off when hot



NOTE: For best results, we recommend performing a TEST prior to starting standard production