



QUICKFLEX

OEKO-TEX®
CONFIDENCE IN TEXTILES
STANDARD 100 

Class 1

*Class 2

						
PU	3 mil	45° Blade	FIRM pressure	330°F	5s	PEEL: HOT

CARRIER: Adhesive & Transparent Polyester

APPLIES ON

- Cotton
- Polyester
- Acrylic & Similar Fabrics

CARE

- Always respect the garment's instructions
- Allow 24 hours after application before washing
- Iron the backside only

WASH

- Max 140°F
- Preferably inside out
- Do NOT bleach
- Tumble-dry
- Do NOT Dry-clean

STORE

- Up to 1 year
- In a dry room (60-85°F)
- Away from sunlight
- In vertical position

APPLICATION

1. Cut the material in reverse with the recommended blade
2. Weed the excess material
3. Heat press on the garment at 330°F & Protect the polyester carrier with silicone paper 5 sec -firm pressure
4. Peel the carrier off when hot



NOTE: For best results, we recommend performing a TEST prior to starting standard production