

# 1602 SUBLIFLOK



CARRIER: Paper

## APPLIES ON

-  Cotton
-  Polyester
-  Acrylic & Similar Fabrics

## CARE

- Always respect the garment's instructions
- Allow 24 hours after application before washing
- Iron the backside only

## WASH

- Max 140°F
- Preferably inside out
- Do NOT bleach
- Tumble-dry
- Do NOT Dry-clean

## STORE

- Up to 1 year
- In a dry room (60-75°F)
- Away from sunlight
- In vertical position, in a plastic bag protected from dust

## APPLICATION

1. Prepare your design right-reading (DO NOT MIRROR) following the instruction of the printer manufacturer. NOTE: It is recommended to use OEM printer inks. Printable medias are very sensitive: always handle with care, preferably with gloves.
2. Set your printing temperature to 45°C and drying temperature to 50°C.
3. Use the adequate printing profile.
4. Remove the product from the printer. NOTE: just after printing, heat press the logo immediately to fix the color, whether onto the fabric or not.
5. Weed the excess material.
6. The use of application tape is optional. It is possible to transfer your design by hand or with a clear polyester application tape. Do not use a paper application tape.
7. Position and heat press the logo onto the garment protected by a silicone paper at 340°F during 50 seconds.
8. For sensitive garments: First, heat press at 340°F-50s while still on the carrier. Then remove the carrier and heat press the logo on the garment at 320°F during 20 seconds.



NOTE: For best results, we recommend performing a TEST prior to starting standard production