

1603 SUBLITEX

OEKO-TEX®
CONFIDENCE IN TEXTILES
STANDARD 100 

Class 1

 POLYESTER	 8.5 mil	 60° Blade	 MEDIUM pressure	 340°F	 50s	 PEEL: HOT
--	--	---	---	---	--	--

CARRIER: Adhesive And Clear Polyester

APPLIES ON

-  Cotton
-  Polyester
-  Acrylic & Similar Fabrics

CARE

- Always respect the garment's instructions
- Allow 24 hours after application before washing
- Iron the backside only

WASH

- Max 140°F (For solvents/eco-solvents ink, 100°F)
- Preferably inside out
- Do NOT bleach
- Tumble-dry
- Do NOT Dry-clean

STORE

- Up to 1 year
- In a dry room (60-75°F)
- Away from sunlight
- In vertical position, in a plastic bag protected from dust

APPLICATION

1. Prepare your design right-reading (DO NOT MIRROR) following the instruction of the printer manufacturer. NOTE: It is recommended to use OEM printer inks. Printable medias are very sensitive: always handle with care, preferably with gloves.
2. Set your printing temperature to 45°C and drying temperature to 50°C.
3. Use the adequate printing profile. For eco-solvents inks, ex: Roland COLORIP or VersaWorks, select the profile TTRH.
4. Remove the product from the printer. NOTE: just after printing, heat press the logo immediately to fix the color, whether onto the fabric or not.
5. Weed the excess material.
6. The use of application tape is optional. It is possible to transfer your design by hand or with a clear polyester application tape. Do not use a paper application tape.
7. Position and heat press your logo on the garment protected by a silicone paper at 340°F–50 seconds – medium pressure. (For the solvents/eco-solvents inks, heat transfer one time at 320°F during 20seconds).
8. For sensitive garments: First, heat press at 340°F for 50 seconds while still on the polyester carrier. Then, remove the carrier and heat press the logo on the garment at 320°C during 20 seconds.


Transfer your imagination

NOTE: For best results, we recommend performing a TEST prior to starting standard production